


Bella Tavola™
**FONDUE/
 CHAFING
 BURNER**

BT-4601

**INSTRUCTIONS
 FOR USE**



IMPORTANT


- Read these instructions carefully to familiarize yourself with the appliance before filling.
- Keep these instructions for future reference.
- Use only in a well ventilated area.

ATTENTION

- The BT-4601 Fondue/Chafing Burner does not contain any butane gas when purchased. Please follow the gas filling instructions to make it operational.
- Use only high quality BUTANE FUEL.
- This Burner is equipped with a positive STOPPER mechanism to ensure a safe TURN-OFF.

FUEL FILLING AND REFILLING


1. Use high quality BUTANE FUEL only.
2. Make sure the Burner is switched OFF before filling.
3. Reverse the unit upside down.
4. Insert the fuel container's nozzle vertically in a downward motion into the FILLING VALVE on the bottom of the unit.
5. When the fuel begins to overflow, remove the nozzle from the filling valve to stop the filling operation. It means the unit is full.



IGNITION

After refilling, please allow a few minutes for the fuel to stabilize in the fuel tank. Do not attempt to ignite the unit until the overflow fuel evaporates.

1. Always place the burner on an even, non-slip surface before ignition.
2. Press down the STOPPER and turn the GAS CONTROL / ON-OFF knob to the left (counterclockwise) to turn on the gas.
3. Push in the GAS CONTROL / ON-OFF to ignite the flame.




FLAME ADJUSTMENT

After the ignition, please follow the flame marks on the clear label to adjust the flame at the minimum, middle and maximum setting.



SHUT OFF

Turn the GAS CONTROL / ON-OFF knob to the right (OFF position), until you hear a "click" sound to ensure a safe TURN-OFF. Make sure that the flame is completely off before storing.



Bella Tavola™

WWW.BELLATAVOLATOOLS.COM

©2011 Wall Lenk Corporation.
 All Rights Reserved.