

ESCALI CORPORATION
3203 Corporate Center Drive, Suite 150
Burnsville, MN 55306
USA

PRODUCT SUPPORT
24/7 Online support: <https://escali.zendesk.com>
Email support: feedback@escali.com
Phone support: 1-800-467-6408

Escali

**PRODUCT
MANUAL**

Vera
Compact Digital Scale
Model # PR2000S



LIFETIME LTD WARRANTY

This scale is guaranteed to be free of defects in materials and workmanship. For more details visit: www.escali.com/warranties

Escali's liability is limited to two (2) times the cost of the product.

© Escali Corp., Minneapolis, MN, USA. All rights reserved. Escali, the Escali logo and other Escali marks are owned by Escali Corp. and may be registered.

www.escali.com

Thank you for purchasing the Escali Vera Digital Scale.

Please read the following operation information to ensure the proper function of your new scale.

HOW TO WEIGH

1. Press the **TARE** key. All display segments will appear for approximately 3 seconds before resetting to zero.
2. Press the **UNIT** key to select the units.
(g, ml, oz, lb + oz, or fl oz)
3. Slowly place an item on the platform, and the weight will be shown on the display.
4. Remove the item. Press and hold the **TARE** key to turn the scale off.

HOW TO USE THE “TARE” FEATURE

This feature allows you to obtain the exact weight of an item in a container by subtracting the weight of the container.

1. Slowly place the container, without the item, on the platform.
2. Press the **TARE** key. The weight of the container will be removed, and the display will reset to zero.
3. Slowly add the item to the container. The display will show the weight of the item only.
4. You may continue to determine the weight of each additional item as they are added by repeating steps 2 & 3.


HOW TO CLEAR THE “TARE” FEATURE

1. Remove all items from the platform.
2. Press the **TARE** key.

BACK-LIGHT DISPLAY

- The back-light will turn on with the scale, and when a button is pressed, or when an item is placed on the scale.
- The back-light turns off after 10 seconds of inactivity.

WARNING MESSAGES

- 0-Ld Overload warning
 Low battery indicator

ATTENTION! Do not place overweight items on scale.

PROPER USE & CARE

- Use and stow the scale at room temperature.
- Use on a flat, level, and stable surface.
- The scale is an instrument of precision. Do not submit the scale to shaking, excessive vibration or other rough treatment.
- The display may be affected by electromagnetic disturbances such as radios, microwaves, or cell phones. If such disturbances occur, remove the source of the disturbance, and restart the scale.
- Disassembling or tampering with the scale voids the warranty.
- Clean the scale with dish soap, and a damp cloth.
- Do not submerge in liquid; the scale is not waterproof.
- For best results, use alkaline batteries.
- Install only new batteries of the same type in your product.
- Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
- Do not mix old and new batteries.
- Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
- Do not dispose of batteries in fire.
- Batteries should be recycled or disposed of as per state and local guidelines.

PRODUCT SPECIFICATIONS

Model: PR2000S

Capacity: 4 lb+6 oz / 2000 g

Graduation: 0.1 g / 0.01 oz (if under 500 g / 17.63 oz)
1 g / 0.1 oz (if over 500 g / 17.63 oz)

Product Dimensions: 6.75” x 4.75” x 1”

Platform Dimensions: 4.75” x 4.75”

Power Source: 2 - AAA batteries (included)

Automatic shut-off: 5 minutes

Back light shut-off: 10 seconds of inactivity