

ENGLISH

Thank you for purchasing an **Escali** Digital Scale.

Please read the following operation information to ensure the proper function of your new scale.

How to weigh

- 1) Press the power key. All display segments will appear for approximately 2 seconds before resetting to zero.
- 2) Press the UNIT key to select the units (Lb+oz, Fl Oz, Gr, Oz or Ml).
- 3) Place item slowly on the platform.
- 4) Press the power key to turn the scale off

How to use the "Tare" feature

This feature allows you to obtain the exact weight of an item in a container, by subtracting the weight of the container.

- 1) Place the container, without the item, slowly on the platform.
- 2) Press the TARE key. The weight of the container will be removed and the display will reset to zero.
- 3) Slowly add the item to the container. The display will show the weight of the item only.
- 4) You may continue to determine the weight of each additional item as they are added by repeating steps 2 & 3.

How to clear the "Tare" feature

Remove all items from the platform and press the TARE or power key.

Hold feature to weigh oversized items that block the display

- 1) Press the HOLD key.
- 2) Place an item on the scale, a beep sound is heard when the weight is stable.
- 3) Remove the item, and the weight will show on the display for 5 seconds.

Do not place overweight items on the scale

Weighing items over the maximum weight capacity will cause an overload "O-Ld" error to display. Immediately remove overweight items to avoid causing damage to your scale.

Battery Replacement

Replace the batteries when the low battery symbol appears on the display.

Additional Information

- 1) Make sure your scale is at room temperature, and on a stable horizontal surface free of vibration.
- 2) This scale is not waterproof. Do not expose to moisture.
- 3) As this scale is a precision instrument, it must be handled with extreme care. Avoid rough treatment, shaking and vibration.
- 4) Do not disassemble this scale or the warranty will be void.

Specifications

Capacity:	7000 gram / 15 Pound / 248 ounce
Increments:	1 gram, 0.1 ounce (1/10th oz.)
Weight Modes:	Gram, Milliliters, Ounces, Pounds+ounces and Fluid Ounces
Auto Shut Off:	Turns off after 5 minutes of non-use.
Power Source:	2 (two) CR2032 Lithium batteries

Escali's liability is limited to two (2) times the cost of the product.

Escali[®] *Measuring What's Next*[™]

User Manual
Bedienungsanleitung
Guide d' utilisateur
Manual del Usuario
Gebruiksaanwijzing



Anti

Digital Scale
Digitale Waage
Balance Digitale
Bilancia Digital
Digitale Weegschaal



see www.escali.com for full details

www.Escali.com

© Copyright Escali Corp, 2011